


← DP1000 → * RIBBON → * SYSTEM 80 →

\overline{RAS}	1	RED	43
\overline{SYSRES}	2	BRN	46
-	3	YEL	NC
A10	4	ORG	26
A12	5	BLU	29
A13	6	GRN	27
A15	7	GRY	21
GND	8	PURP	49-50
A11	9	BLK	28
A14	10	WHT	23
A8	11	RED	22
\overline{OUT}	12	BRN	NC
\overline{WR}	13	YEL	40
[\overline{IORQ}] *	14	ORG	38
\overline{RD}	15	BLU	41
-	16	GRN	NC
A9	17	GRY	24
D4	18	PURP	20
\overline{IN}	19	BLK	NC
D7	20	WHT	17
\overline{INT}	21	RED	31
D1	22	BRN	14
-	23	YEL	NC
D6	24	ORG	18
A ϕ	25	BLU	10
D3	26	GRN	16
A1	27	GRY	7
D5	28	PURP	11
GND	29	BLK	1-2
D ϕ	30	WHT	15
A4	31	RED	6
D2	32	BRN	12
\overline{WAIT}	33	YEL	37
A3	34	ORG	8
A5	35	BLU	5
A7	36	GRN	3
GND	37	GRY	1-2
A6	38	PURP	4
VCC	39	BLK	NC
A2	40	WHT	9



NOTES

CABLE ASSEMBLY
BETWEEN
DP1000 & SYSTEM

USE 50WAY EDGE
CONNECTOR AS
SHOWN ON
SEPARATE SHEET

NB NUMBERS
CONNECTOR

SHOULD BE IGNORED
REFER TO NUMBERS
ON DP1000 &
SYSTEM 80, WHICH
ARE NON-STANDARD

* SMALL MOD
REQUIRED IN SOME
DP1000, SEE
SEPARATE SHEET
(FOR PRINTER
USE ONLY)

30 AUG 80